

Pre Dye Colour Remover

brings fabric to a neutral shade ready for dyeing



- Use when you want to dye a dark fabric to a lighter colour, e.g. from Navy to Light Blue, or to change fabric from one strong colour to another e.g. from Red to Blue.
- Pre-Dye Colour Remover for Hand use is specially formulated for hand use on small or delicate items on the stove top.
- NOT recommended for use on items with special finishes, e.g. 'dry clean only', waterproof or for pure polyester/acrylic.



Which fabrics can you treat?

Fabric Colour Stripper	Hand use
Cotton	<input checked="" type="checkbox"/>
Linen	<input checked="" type="checkbox"/>
Viscose	<input checked="" type="checkbox"/>
Wool	<input checked="" type="checkbox"/>
Silk	<input checked="" type="checkbox"/>
Nylon	<input checked="" type="checkbox"/>
Lycra	<input checked="" type="checkbox"/>
Poly/cotton	<input type="checkbox"/>



Top – original colour



Top – stripped with Pre-Dye



Top – re-dyed with Machine Dye in Cherry Red

USE BY HAND:



Colour with confidence